


BATTERY MELTER

FOR MELTING OF HARD WAX
AND CERAMIC FILLER



picobello[®]
Maintain, Clean and Repair like the professionals

IT'S JUST SO EASY...

The Picobello Battery Melter is designed for the melting of fillers like hard wax and ceramic filler. The melter is powered by 3 x AA size batteries. The melter has a curved tip for mixing and optimal handling of the fillers - even in corners and edges. Handling and operation are simple.



Uses: To operate the melter, you require three 1.5V AA batteries. Insert the batteries as shown in the picture. Before operating the melter, take off protective cap. and set the yellow slide to the „ON“ position. To heat the melter, press and hold down the blue button for 10-15 seconds. A red light indicates that the melter is heating up. Should the Hard Wax start smoking during melting, release the „ON“ button – the tip cools down slowly. You can increase the temperature at any time while pressing the „ON“ button. Please do not forget to replace the cap when melter is no longer needed.



Safety Instructions for Battery Melter: Always store melter with cap fitted and ensure ON/OFF switch is set to OFF position. Tip becomes hot during operation. Never bring the tool into contact with water. After operation, allow tip to cool down before storage. Always turn off melter after operation, while pushing the switch into the OFF position.



Disposal of electrical and electronic appliances and components:

For the sake of our environment and in order to recycle as completely as possible the raw materials used, the end-user is requested to deliver used or defective appliances to a public waste collection point for electronic scrap. A crossed-out wheeled bin symbol indicates that the product is to be delivered to a collection point for electronic scrap to ensure that raw materials are recycled in the best possible way. Thus, you fulfil your legal duties and contribute to environmental protection!